


Knowledgebase > FAQs by core architecture > RH850 > [RH850] SYStem.Up / SYStem.Attach returns "debug port fail"

[RH850] SYStem.Up / SYStem.Attach returns "debug port fail"

2025-10-09 - Comments (0) - RH850


"debug port fail" Error in Debugging Mode

If you get a "debug port fail" error message after a a **SYStem.Up** or **SYStem.Mode Attach**, then please first try to use the AutoSetup dialog to connect to the target by selecting the menu **RH850 > Auto Setup** in the TRACE32 PowerView user interface of by calling the script ~~/demo/rh850/flash/rh850_autosetup.cmm available in the TRACE32 demo directory:



D0 ~~/demo/rh850/flash/rh850_autosetup.cmm

The script opens the following dialog:



Set the mode to "AutoSetup for Debugging" then press OK.

If you still get the "debug port fail" error, then please check the following:

Your TRACE32 version might be too old. It is recommended to use the latest TRACE32 release available
for download on the <u>Lauterbach website</u>. In such cases, you would get a message indicating this in the
AREA window:

```
DBG_LUT_PE3 = 0x00000000


DBG_LUT_PE4 = 0x00000000

DBG_LUT_PE5 = 0x000000000


DBG_LUT_PE6 = 0x000000000

ERROR: TRACE32 does not support the detected CPU = R7F701442 debug hardware configuration error
```

- The used JTAG clock might be too high (JTAG mode only). Try a lower JTAG clock using the command SYStem.JtagClock e.g. SYStem.JtagClock 1MHz
- If you are using LPD mode, then try different baud rate values using the command SYStem.BAUDRATE or using the BAUDRATE pulldown menu in the SYStem window



 For the G3-core variants, the selected debug port type (JTAG / LPD4 / LPD1) might not match the Option Bytes. Please try different debug port types using the command SYStem.CONFIG DEBUGPORTTYPE



• If the RDY-line is not connected then you should use **SYStem.Option.RDYLINE OFF**. The RDY-line is a CPU output signal located on pin 11 of the debug connector. This signal informs the debugger when a CPU can accept the next JTAG command. TRACE32 assumes per default that the RDY-line is connected. If **SYStem.Option.RDYLINE** is set to **OFF** then TRACE32 will get the "ready-status" by polling the CPU

debug registers. Disabling the RDY- line has no impact the on debug functionality, but causes loss of performance in the JTAG communication.

Signal	Pin			Pin	Signal
TCK	1	- 10	an.	2	GND
TRST-	3	- 10	- 10	4	FLMD0
TDO	5	- 10		6	(FLMD1)
TDI	7	- 10	- 10	8	VCC
TMS	9	- M		10	(FLMD2)
RDY-	11	- M	- 10	12	GND
RESET-	13	al.	M.	14	GND

- The problem could be caused by a bad quality of the debug signals e.g. reflections on TCK line. Please check the debug signals, especially TCK with a scope. A serial termination at TCK (e.g. 50..1000hm) between target and debugger may solve the problem in such cases. Check moreover if the FLMD0 signal is correctly connected. Board designer should locate the debug connector as close as possible to the processor to minimize the capacitive influence of the trace length and cross coupling of noise into the debug signals.
- The RESET signal of the CPU might be not properly connected. Check the voltage level with an oscilloscope. The RESET signal should toggle at **SYStem.Up**. Check additionally if the CPU is permanently in reset.
- The problem may be caused in some cases by the target application: when a debug tool tries to connect
 to the CPU, the application code is already running (not for G4-core variants). Application code may
 disturb the debug-connection process. A workaround is to patch a jump to the same address at the reset
 vector. Refer for more information to the RH850 Debugger and Trace manual under Useful Tips >
 Application Starts Running at SYStem.Up.

addr/line		label	mnemonic	
P:00000000			nop	
P:00000002			nop	
P:0000004	0000		nop	
P:00000006	07800000		jr	0x6

• Debug interface might be locked. Please refer to the description of the following three commands in the RH850 Debugger and Trace manual for more information:

SYStem.Option OCDID < value > ; unlocks the debug access


SYStem.Option CFID < value >; unlocks the code flash access

SYStem.Option DFID < value >; unlocks the data flash access

ID-Code-Protection Unit might be locked (G3K-core variants only). You can use in this case the command
 SYStem.Option KEYCODE < value >


"debug port fail" Error in Serial-Flash-Programming Mode

First try to use the AutoSetup dialog by selecting the menu $\bf RH850 > Auto~Setup$ in the TRACE32 PowerView user interface of by calling the script ~~/demo/rh850/flash/rh850_autosetup.cmm available in the TRACE32 demo directory:



DO ~~/demo/rh850/flash/rh850 autosetup.cmm

The script opens the following dialog, select "AutoSetup forSerial-Flash-Programming" and press OK:



If you still get an error, the try the following:

- Check the BAUDRATE: try different values
- OSCCLOCK and CORECLOCK have to match the target oscillator frequency and CPU Core-Clock. AREA window gives an indication about valid values

 $\bullet\,$ Check if the FLMD0 signal is correctly connected

If the issue persists

- Detailed description of the issue
- Screenshots that show the issue
- Which CPU and target are used?
- Generate a system information report about your TRACE32 configuration by selecting the TRACE32 menu 'Help' > 'Support' > 'System Information...', click 'Save to File'
- The content of the AREA window
- Tags
- <u>RH850</u>