[MPC5xxx] Why do I get power-fail messages even though the target power is correct at the reference pin?

2026-08-11 - Comments (0) - MPC5xxx / SPC5xx

If `SYStem.Up` fails and the debugger reports a power-fail condition, check whether two debuggers are connected to the target at the same time, for example a JTAG dongle and a NEXUS probe.

This is an unsupported configuration and prevents both the JTAG dongle and the NEXUS probe from being used for debugging