# [Arm] Is it possible to attach to the target without resetting the onchip trace?

2022-01-11 - Comments (0) - Arm

You should use the following command sequence to attach to the target without losing the onchip trace contents, e.g. in case the onchip trace has already been set up by the target application and should not be reset by the debugger:

    Onchip.DISable
    Onchip.Attach
    SYStem.Mode Attach
    Break

The trace contents can be then displayed using the command **Trace.List**

- Tags
- Arm
- Trace