



[Support Center](#) > [Community](#) > [Test Automation](#) > [getting "lauterbach.trace32.rcl\\_rc\\_variable.VariableError: \(65535, ''\)" after continous read](#)

## getting "lauterbach.trace32.rcl\_rc\_variable.VariableError: (65535, '')" after continous read **Awaiting Agent**

- AA Ahmed Abdelgaber
- **Forum name:** #Test Automation

Hi, I am trying to read variables through python lauterbach.trace32.rcl package.  
my test requires reading a lot of variables and this set of variables re-read several times with different inputs changes,

after some successful read commands, I am getting this error:  
raise VariableError(result.err\_code, result.err\_msg)  
lauterbach.trace32.rcl\_rc\_variable.VariableError: (65535, '')

Here is a simplified script to reproduce the issue:

```
import lauterbach.trace32.rcl as t32
import time
t32_inst = t32.connect()
count = 1
while True:
    value = t32_inst.variable.read()
    time.sleep(0.2)
    print (f"count {count}, value {value}")
    count+=1
```

So, would you please help me overcoming this issue?  
Thanks,

### Comments (3)

AA Ahmed Abdelgaber

5 months ago

For me, I am getting this error after 1048 successful read

**Wiem Wala Benayed**

5 months ago

Hello,

You need to use recent version of TRACE32. (ex R2025.02)

Regards,

Wiem

**AA Ahmed Abdelgaber**

2 months ago

worked, many thanks @Wiem!!