




Knowledgebase > TRACE32 PowerView > How can I check if a specific processor/chip is supported by TRACE32?

How can I check if a specific processor/chip is supported by TRACE32?

2025-08-02 - Comments (0) - TRACE32 PowerView

Start by checking the Lauterbach website: www.lauterbach.com. Use the search to see if your CPU is listed as supported.

You can also start TRACE32 PowerView for your target processor architecture, and search directly in the user interface by entering the command `SYStem.CPU` in the command line. Wildcards are accepted:



Keep in mind:

- The CPU might be supported in a newer software release than the one you are currently using. If in doubt, download the latest version from the [Lauterbach Customer Portal](#).
- Confidential CPU selections are **not** listed on the website or via `SYStem.CPU`.

If you can't find your CPU, contact the Lauterbach support by [submitting a support ticket](#).