Is it possible to display multiple terminal windows in the same time with TRACE32 PowerView?

2026-04-01 - Comments (0) - TRACE32 PowerView

TRACE32 PowerView can display up to 16 separate terminal windows at the same time.
The method can be defined with an index using the command **TERM.METHOD # ...** The same index can then be used to open the terminal window.

Example:

```
For channel 1 --> TERM.METHOD #1 SingleE 0x1 0x1
For channel 2 --> TERM.METHOD #2 BufferE 0x2 0x2
For channel 1 --> TERM.view #1
For channel 2 --> TERM.view #2
```

Further information can be found in General Commands Reference Guide T

- Tags
- TERM