



[Knowledgebase](#) > [TRACE32 PowerView](#) > [Is it possible to display multiple terminal windows in the same time with TRACE32 PowerView?](#)

Is it possible to display multiple terminal windows in the same time with TRACE32 PowerView?

2026-04-01 - [Comments \(0\)](#) - [TRACE32 PowerView](#)

TRACE32 PowerView can display up to 16 separate terminal windows at the same time. The method can be defined with an index using the command **TERM.METHOD # ...**. The same index can then be used to open the terminal window.

Example:

```
For channel 1 --> TERM.METHOD #1 SingleE 0x1 0x1
For channel 2 --> TERM.METHOD #2 BufferE 0x2 0x2
For channel 1 --> TERM.view #1
For channel 2 --> TERM.view #2
```

Further information can be found in [General Commands Reference Guide T](#)

- [Tags](#)
- [TERM](#)