

Knowledgebase > TRACE32 PowerView > Is it possible to display multiple terminal windows in the same time with TRACE32 PowerView?

Is it possible to display multiple terminal windows in the same time with TRACE32 PowerView?

2025-10-09 - Comments (0) - TRACE32 PowerView

TRACE32 PowerView can display up to 9 separate terminal windows at the same time.

The method can be defined with an index using the command **TERM.METHOD # ...** The same index can then be used to open the terminal window.

Example:

For channel 1 --> TERM.METHOD #1 SingleE 0x1 0x1 For channel 2 --> TERM.METHOD #2 BufferE 0x2 0x2 For channel 1 --> TERM.view #1 For channel 2 --> TERM.view #2

Further information can be found in General Commands Reference Guide T

- Tags
- TERM