



Knowledgebase > FAQs by core architecture > MPC5xxx / SPC5xx > [MPC5xxx] How to manage external watchdog timer control?

[MPC5xxx] How to manage external watchdog timer control?

2022-01-11 - Comments (0) - MPC5xxx / SPC5xx

Please see section "**Watchdog Timer Support**" in [Qorivva MPC5xxx/SPC5xx Debugger and NEXUS Trace](#).