Regenerating coverage information after changing metric?

2022-01-12 - Comments (0) - Code coverage

The coverage information is processed at the same time for all coverage metrics using the command **COVerage.ADD**. The displayed metric can be changed after executing this command

To change the displayed metric, either execute **COVerage.Option.SourceMetric <** *metric* **>** (e.g. **COVerage.Option.SourceMetric Statement**) or set the metric in the **COVerage.state** window.

Please refer for more information to the documentation of the COVerage commands in General Command Reference Guide C and to the Application Note for Trace-Based Code Coverage.