Which 3rd party software components are used by TRACE32 PowerView?

2026-04-01 - Comments (0) - TRACE32 PowerView

TRACE32 provides details about all 3rd-party software components, including version and licensing information, in two ways:

- By using the TRACE32 command:

  VERSION.ThirdPartyLicenses

- In the installation directory, The folder licenses contains:

  - The file readme_3rd-party-software.txt, which lists all components with version and license details.

  - Individual files for each 3rd-party component, including copyright notices and full license texts.