




[Knowledgebase](#) > [FAQs by core architecture](#) > [Arm](#) > [Why do I get the error "no MMU table format defined" in MMU.DUMP PageTable?](#)

Why do I get the error "no MMU table format defined" in MMU.DUMP PageTable?

2026-06-19 - [Comments \(0\)](#) - [Arm](#)

This error message appears in the output of `MMU.DUMP PageTable` or `MMU.List PageTable` when the MMU registers—particularly the Translation Control Register (TCR)—contain invalid or undefined values. These values are required to determine the format of the page table.



To resolve this, use the `MMU.View` command to inspect the current values of the MMU-related registers and verify that they are correctly initialized.