



[Support Center](#) > [Community](#) > [Debugging](#) > [FreeRTOS-SMP Debugging](#)

FreeRTOS-SMP Debugging

- RR Rohith R
- **Forum name:** #Debugging

Hi Team,

I am trying to debug FreeRTOS-SMP on quad core using Trace 32.

(i) I want to know How can I see the registers of all the 4 cores at a time?

(ii) Also How can I debug (step into the codes ) all the 4 cores at the same time .

To do all these what changes I have to do in the .cmm file

Comments (5)



**Khaled Jmal**

1 year ago

Hello Rohit, first, you use an SMP CPU selection in TRACE32 PowerView. If you can give me more information about your target processor, then I could help you more with this. Please then have a look to "SMP Concept" and "Basic Debugging (SMP)" in

[https://repo.lauterbach.com/pdf/training\\_debugger\\_smp.pdf](https://repo.lauterbach.com/pdf/training_debugger_smp.pdf)

**RR Rohith R**

1 year ago

My target processor contain 4 A53 core. So that I have to run the code on all this 4 cores. I can load and run the program but i don't know on which core the code is running. I want to view the registers of all cores as a part of debug. I need 4 debug windows ,one for each core so that when i step in the code i can see it on all the 4 cores. Here I am adding some portion of my .cmm file. SYStem.CPU XXXX SYStem.CONFIG CORE 1. 1. CORE.ASSIGN 1. 2. 3. 4.

```
***** Data.LOAD.Elf "xxx_smp.elf" ;.out smp file for 4 core
```

```
Register.Set PC _init_ /CORE 1. Register.Set PC _init_ /CORE 2. Register.Set PC _init_ /CORE 3.
```

Go \_init\_ Mode.HII WinPOS 0. 0. 116. 26. List.auto By this code a single window with \_init\_ code portion will come.It may be the 4th core.



**Khaled Jmal**

1 year ago

You need to open a List window with the /CORE option: List.auto /CORE 0 List.auto /CORE 1 List.auto /CORE 2 List.auto /CORE 3

**RR Rohith R**

1 year ago

I have tried with this. Now I can see the code snippet and registers of all the 4 cores at the same time. But Now there is a problem when debugging, step in it is not properly step in all the 4 core simultaneously. Is it the issue with .cmm file?

**RR Rohith R**

1 year ago

Also List /CORE Register.view /CORE Go \_\_system\_start List /CORE 1. Register.view /CORE 1. Go \_\_system\_start List /CORE 2. Register.view /CORE 2. Go \_\_system\_start List /CORE 3.

Register.view /CORE 3. Go `__system_start` When I use this code snippet to debug from `__system_start` in all the 4 cores, core1, core2 and core3 is available. Core 0 `__system_start` and its registers are not available.