



[Support Center](#) > [Community](#) > [Board Bring-Up](#) > [Issues in setting endianness using CMM file in RX72N processor](#)

Issues in setting endianness using CMM file in RX72N processor

- SV Suriyanarayanan Parthasarathi Vimala
- **Forum name:** #Board Bring-Up

Hi, Good day.

I am working on RX72N processor and for the project needs, we need to set this as Big Endian from the trace32 cmm file. I have seen the samples provided by Trace32 folder and took a reference of it for the requirement of changing the endian.

The problem what I am seeing is that even when I change the values of MDE register to Big Endian (0xf8f8f8f8) in the cmm file, the values are not reflecting back and still it is in the Little Endian value 0xffffffff. Attaching the piece of code that I expect to work. Also attaching the whole cmm file with it for reference.

\*\*\*\*\*

```
; Setting the Big Endian directly on the MDE register
&mde=0xf8f8f8f8
FLASH.AUTO.ALL /CENSORSHIP
Data.Set 0xFE7F5D00 %Long &mde
```

```
FLASH.AUTO.off
SYStem.Up ; force RESET to sample new endianness
GOSUB ENDIANESS ; get target endianness
GOSUB FLASHSETUP ; Flash declaration + Binary selection
GOSUB PLLINIT ; PLL setup for 12MHz crystal -> 96MHz system-clk
```

```
ENDIANESS:
```

```
&TargetEndian=Data.Long(D:0xFE7F5D00) ; MDE register
```

```
IF (&TargetEndian==0xffffffff)
```

```
(
```

```
; ***** Expecting it to come here but it is not *****
```

```
SYStem.Option BE OFF
```

```
PRINT "Target: Little Endian"
```

```
)
```

```
ELSE
```

```
(
```

```
SYStem.Option BE ON
```

```
PRINT "Target: Big Endian"
```

```
)
```

```
*****
```

Let me know if I am missing anything in the code. Also, let me know if you need anything.

Comments (2)

**SV Suriyanarayanan Parthasarathi Vimala**

1 year ago

; \*\*\*\*\* Expecting it to come here but it is not \*\*\*\*\* Expecting this in else loop, I made a typo in the wrong section.



**Khaled Jmal**

1 year ago

Hello, sorry for the late reply. This was due to an error in the Flash binary which has been fixed now. Please request a nightly software update by opening a ticket at [support.lauterbach.com/new-ticket](https://support.lauterbach.com/new-ticket) and refer to this community post. Regards, Khaled