



[Support Center](#) > [Community](#) > [Debugging](#) > [Watch variable while running for ARM/Zynq-7000](#)

Watch variable while running for ARM/Zynq-7000 **Awaiting Agent**

- CN Csaba Nemes
- **Forum name:** #Debugging

Hello, I have a Xilinx Zynq-7000 device, and I would like to watch a variable in Trace32 real-time, while the target is running.

I have configured the memaccess like so:

```
SYStem.MemAccess.DAP
```

I have also tried the %E switch:

```
Var.View %E my_variable
```

However, it does not work. When the %E is applied, the value is always 0, without the %E it only works when I break the execution.

What am I missing? Thanks.

Comment (1)

Oussema Koubaa

4 months ago

Hello, To ensure a proper support of this core, please open a new ticket:

["https://support.lauterbach.com/new-ticket"](https://support.lauterbach.com/new-ticket) and send the script you are using, a screenshot of the mentioned Var.Watch window and please generate a system information report about your TRACE32 configuration by selecting the TRACE32 menu 'Help' > 'Support' > 'System Information...', click 'Save to File' and send the resulting text file as an attachment to your e-

mail. Best Regards, Oussema