

Knowledgebase > Tracing > How to calculate the minimum trace line number for Arm parallel trace

## How to calculate the minimum trace line number for Arm parallel trace

2023-10-25 - Comments (0) - Tracing

The official recommendation from arm is that the optimal bandwidth = 2bit\*core frequency. For example if the core is running at 500MHz with a trace clock = 80 Mhz = 160 Mhz DDR, the number of trace line needed:

optimal bandwidth / 1 line bandwidth = 2\*500Mhz/160 = 6.25 trace line

So with a single core running at 500 Mhz, and 80Mhz trace clock TPIU.PortSize 8 should be fine.

With 2 cores you need 2\*bandwidth  $\rightarrow$  12,5 trace line, so you need TPIU.PortSize 16